
List of tables

Table 1	
Trunk card characteristics	8
Table 2	
Differences between PE and IPE modules	16
Table 3	
Trunk and signaling matrix	30
Table 4	
Universal trunk card—trunk interface electrical characteristics	68
Table 5	
Power requirements	69
Table 6	
Environmental specifications	69
Table 7	
Universal trunk card—backplane pinouts	71
Table 8	
Jumper strap settings—factory standard (NT8D14BA, NT8D14BB) .	74
Table 9	
Jumper strap settings—extended range (NT8D14BA, NT8D14BB, NT8D14BB Release 10 and up)	75
Table 10	
Trunk types—termination impedance and balance network (NT8D14BA, NT8D14BB)	78
Table 11	
Cable loop resistance and loss	78

Table 12	
Pad switching algorithm	80
Table 13	
Trunk and signaling matrix	84
Table 14	
Operation mode	98
Table 15	
DX signaling—outgoing calls with originating party release	102
Table 16	
DX signaling—incoming calls with originating party release	103
Table 17	
DX signaling—outgoing calls with originating party release on tandem connections	104
Table 18	
DX signaling—incoming calls with originating party release on tandem connections	105
Table 19	
Electrical characteristics	106
Table 20	
Power requirements	107
Table 21	
Environmental specifications	107
Table 22	
E&M trunk card—backplane pinouts for 2-wire modes	108
Table 23	
E&M trunk card—backplane pinouts for 4-wire modes	109
Table 24	
E&M trunk card—jumper strap settings	113
Table 25	
Pad switching algorithm	115
Table 26	
DX signaling for outgoing calls, originating party release	125

Table 27	
DX signaling for incoming calls, originating party release	126
Table 28	
DX signaling, originating party release on tandem connections, outgoing calls	127
Table 29	
Class of service modes	130
Table 30	
DX signaling, originating party release on tandem connections, incoming calls	134
Table 31	
Trunk interface electrical characteristics	135
Table 32	
Power requirements	136
Table 33	
Environmental specifications	136
Table 34	
E&M/DX and paging trunk card—backplane pinouts	139
Table 35	
E&M/paging trunk card—option switch settings	140
Table 36	
Intercept treatment and associated types of announcements	154
Table 37	
Trunk interface electrical characteristics	158
Table 38	
Recorded announcement trunk card—power requirements	159
Table 39	
Environmental specifications	159
Table 40	
Recorded announcement trunk card—backplane pinouts	161
Table 41	
Recorded announcement trunk card—switch settings for units 0 and 1	164

Table 42	
Recorded announcement trunk card—switch settings for units 2 and 3	164
Table 43	
Start modes	183
Table 44	
DX signaling—originating party release	192
Table 45	
DX signaling—originating party release on tandem connections for outgoing calls	193
Table 46	
DX signaling—originating party release on tandem connections for incoming calls	194
Table 47	
Electrical characteristics	195
Table 48	
Power requirements	196
Table 49	
Environmental specifications	196
Table 50	
4-wire E&M/DX trunk card—connections	198
Table 51	
4-wire E&M trunk card—S1 and S2 switch settings	202
Table 52	
4-wire E&M trunk card—S3, S4, S5, and S6 switch settings	203
Table 53	
Connections to recording machines	210
Table 54	
Trunk interface electrical characteristics	217
Table 55	
Power requirements	218
Table 56	
Environmental specifications	218

Table 57	
Recorded telephone dictation trunk card—connections	220
Table 58	
Recorded telephone dictation trunk card—switch settings	222
Table 59	
Electrical specifications	233
Table 60	
Power requirements	234
Table 61	
Environmental specifications	234
Table 62	
Release link trunk card—backplane pinouts	235
Table 63	
Application and compatibilities	244
Table 64	
Electrical characteristics	250
Table 65	
Power requirements	251
Table 66	
Environmental specifications	251
Table 67	
Loop signaling trunk card—backplane pinouts	254
Table 68	
Trunk characteristics	274
Table 69	
Power requirements	275
Table 70	
Environmental specifications	275
Table 71	
CO/FX/WATS trunk card—backplane pinouts	278

Table 72	
QPC450A&B vintage CO/FX/WATS trunk card—switch and jumper settings	281
Table 73	
QPC450C CO/FX/WATS trunk card—switch settings	282
Table 74	
QPC450C1 & D CO/FX/WATS trunk card—switch settings	283
Table 75	
QPC450 E&F trunk cards—switch settings	284
Table 76	
QPC450G CO/FX/WATS trunk card—switch settings	285